

PROJECT NAME : AnnonaSense CLR™



FORMULA NAME : Derma IQ Jelly Face Scrub

TRIAL CODE : 110.006.02

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	56.34
A	Amaze XT	Dehydroxanthan Gum	Nouryon	1.00
B	Ethanol (96%)	Alcohol	BerkeL AHK	15.00
B	Glycerin 86%	Glycerin Water	Gustav Heess	5.00
B	Plantacare 2000 UP	Decyl Glucoside	BASF	6.00
B	Dehyton MC	Sodium Cocoamphoacetate	BASF	5.50
B	Microcare SBB	Benzyl Alcohol Benzoic Acid Sorbic Acid	THOR	1.00
B	MultiMoist CLR™	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	3.00
B	ProRenew Complex CLR™ NP	Lactococcus Ferment Lysate	CLR	3.00
B	Citric Acid Anhydrous	Citric Acid	N.A.	0.66
C	AnnonaSense CLR™	Annona Cherimola Fruit Extract	CLR	3.00
D	Gotalene RS 410 Blue 23	Polylactic Acid	Axalta	0.50
				100.00

Operating Instructions

Mix A and stir until uniform. Add B in the given order with moderate stirring. Add B in the given order and adjust pH value to 5.2 before adding C. Slowly add D with moderate stirring.

Directions for use:

Apply in the morning & evening on the wet face, neck & décolleté. Avoid contact with area around the eyes. Massage thoroughly and rinse-off well.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com