

PROJECT NAME : Collagen CLR



FORMULA NAME : Collagen Face Mist

TRIAL CODE : 144.006.04

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	73.55
A	Tylose H 4070 NG4	Hydroxyethylcellulose	Shin-Etsu	0.10
B	Butylene Glycol	Butylene Glycol	Merck	5.00
B	Glycerin 86%	Glycerin Water	Gustav Heess	3.00
B	Trisodium Citrate Dihydrate	Sodium Citrate	Merck	0.35
B	Hydrolite-5	Pentylene Glycol	Symrise	5.00
C	<b>Collagen CLR</b>	Soluble Collagen	CLR	10.00
C	<b>MultiMoist CLR™</b>	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	3.00
				<b>100.00</b>

#### *Operating Instructions*

Add Water, dissolve under stirring (~200rpm) and trickle Tylose slowly into the water. Let it stir for ~ 60 minutes. Add B in the given order and stir until uniform. Add C one after another and stir until homogeneous.

Directions for use:

Spray on the face. Apply in the morning and evening on cleansed skin before your usual routine.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)