

PROJECT NAME : Lactokine™ Fluid PF



FORMULA NAME : Balance Me Body Lotion

TRIAL CODE : 311.002.01A

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	79.25
A	Keltrol CG-BT	Xanthan Gum	CP Kelco	0.50
B	Eumulgin SG	Sodium Stearoyl Glutamate	BASF	0.50
B	Emulgade Sucro Plus	Sucrose Polystearate Cetyl Palmitate	BASF	1.50
B	Cutina GMS-V	Glyceryl Stearate	BASF	1.00
B	Lanette O MB	Cetearyl Alcohol	BASF	1.50
B	Cetiol 868	Ethylhexyl Stearate	BASF	4.00
B	Cetiol RLF	Caprylyl-Caprylate/Caprates	BASF	4.00
B	Cetiol J 600	Oleyl Erucate	BASF	1.50
B	Copherol F 1300 C	Tocopherol	BASF	0.05
B	Cosmedia SP	Sodium Polyacrylate	BASF	0.20
C	Verstatil BOB	Benzyl Alcohol Caprylyl Glycol Benzoic Acid	Evonik	0.80
D	<b>Lactokine™ Fluid PF</b>	Milk Protein	CLR	5.00
E	Perfume Bamboo Palace	Fragrance	Frey+Lau	0.20
				<b>100.00</b>

#### *Operating Instructions*

Heat up A and b to 80°C separately. Add A to B and homogenize for 3 minutes with Ultra Turrax. Cool down while stirring to 30°C. Add C and D. Stir until homogeneous. Add E as desired.

Directions for use:

Apply on the whole body after shower or bath and gently rub into the skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)