

PROJECT NAME : MultiMoist CLR™



FORMULA NAME : Beard Jelly Care

TRIAL CODE : 385.010.04_1

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	88.75
A	Amaze XT	Dehydroxanthan Gum	Nouryon	1.00
B	Verstatil BOB	Benzyl Alcohol Caprylyl Glycol Benzoic Acid	Evonik	1.00
B	ProRenew Complex CLR™	Lactococcus Ferment Lysate	CLR	3.00
B	MultiMoist CLR™	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	3.00
C	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.25
D	AnnonaSense CLR™	Annona Cherimola Fruit Extract	CLR	3.00
				100.00

Operating Instructions

Mix A and stir until completely dispersed or homogenize with Ultra Turrax until uniform. Add B in the given order and adjust pH value to 6-6.5 with C. Add D and stir until homogeneous.

Directions for use:

Take a pea-size, gently massage into the beard.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com