

PROJECT NAME : MultiMoist CLR™



FORMULA NAME : Derma IQ SOS Scalp Ampoule

TRIAL CODE : 385.018.01A_1

Lab Formula INCI Supplier

Phase	Material Name	Mixed INCI	Supplier	% Material
A	DEIONIZED WATER	WATER	N.A.	82.73
A	TYLOSE H 100070 NP2	HYDROXYETHYL CELLULOSE	SHIN ETSU	0.25
A	GLYCERIN 86%	GLYCERIN WATER	GUSTAV HEESS	2.00
A	MICROCARE SB	WATER SODIUM BENZOATE POTASSIUM SORBATE	THOR	0.60
B	EUMULGIN L	PPG-1-PEG-9 LAURYL GLYCOL ETHER	BASF	2.80
B	COPHEROL F 1300 C	TOCOPHEROL	BASF	0.02
B	VITAMIN F FORTE	LINOLEIC ACID LINOLENIC ACID	CLR	0.50
C	MULTIMOIST CLR™	FRUCTOOLIGOSACCHARIDES BETA VULGARIS (BEET) ROOT EXTRACT WATER	CLR	3.00
C	SYRICALM™ CLR (PC)	WATER PHRAGMITES COMMUNIS EXTRACT PORIA COCOS EXTRACT	CLR	3.00
C	ETHANOL (96%) DENATURED	ALCOHOL DENAT.	BERKEL AHK	5.00
D	PERFUME OIL: Apple & Pear	FRAGRANCE	FREY + LAU	0.10
				100.00

Operating instructions

Operating Instructions

Mix A and stir until uniform. Premix B and add to A, stir for a short moment. Add C in this order and stir until uniform. Add D as desired.

Directions for use:

Apply on the affected scalp and gently massage.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com