

PROJECT NAME : ProRenew Complex CLR™



FORMULA NAME : Luxury Well-Being Gel-Mask

TRIAL CODE : 421.019.09A

Lab Formula INCI Supplier

<i>Phase</i>	<i>Material Name</i>	<i>Mixed INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	DEIONIZED WATER	WATER	N.A.	74.85
A	HYDROLITE-5	PENTYLENE GLYCOL	SYMRISE	5.00
A	ARISTOFLEX VELVET	POLYACRYLATE CROSSPOLYMER-11	CLARIANT	0.60
A	GLYCERIN 86%	GLYCERIN WATER	GUSTAV HEESS	3.00
A	HISPAGEL 200 Ns	GLYCERIN GLYCERYL POLYACRYLATE	BASF	10.00
B	PRORENEW COMPLEX CLR™	LACTOCOCCUS FERMENT LYSATE	CLR	3.00
B	ANNONASENSE CLR™	ANNONA CHERIMOLA FRUIT EXTRACT	CLR	3.00
C	NAOH (32%)	WATER SODIUM HYDROXIDE	N.A.	0.20
D	COLORONA PRECIOUS GOLD	MICA (CI 77019) TITANIUM DIOXIDE (CI 77891) SILICA IRON OXIDES (CI 77499, CI 77492, CI 77491) TIN OXIDE	MERCK	0.20
D	PERFUME OIL: Nepal Flowers	FRAGRANCE	FREY + LAU	0.15
				100.00

Operating instructions

Operating Instructions

Mix A and stir slowly until completely soaked. Add B and stir. Adjust pH value to 5.5-6 with C. Add D as desired.

Directions for use:

Apply over clean skin in a thin layer. After 10 minutes, lightly massage residues into the skin or wipe away with tissue.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com