

PROJECT NAME : Repair Complex CLR™ PF



FORMULA NAME : After Sun Treatment

TRIAL CODE : 431.003.11_1

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	90.23
A	Keltrol CG-BT	Xanthan Gum	CP Kelco	0.10
A	Aristoflex Velvet	Polyacrylate Crosspolymer-11	Clariant	0.50
A	Euxyl PE9010	Phenoxyethanol Ethylhexylglycerin	Schuelke	0.80
B	Repair Complex CLR™ PF	Bifida Ferment Lysate	CLR	5.00
B	MultiMoist CLR™	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	3.00
C	NaOH (10%)	Water Sodium Hydroxide	N.A.	0.37
				100.00

Operating Instructions

Mix A and stir until completely dispersed. Add B in the given order and stir until uniform. Add C and adjust pH value to 5-5.5 with C.

Directions for use:

Apply on the face and body after sunbath and gently rub into the skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com